

Integrating Sphere Power Sensor Head with MCT (HgCdTe) Detector

S180C



Description

The Gold-Coated S180C Integrating Sphere Power Sensor Head with MCT (HgCdTe) Detector is designed to measure the optical power of an incoming beam independent of the divergence and beam shape. This Mid-IR power meter sensor head has an optical power working range from 1 μ W to 3000 mW and a wavelength range of 2900 nm to 5500 nm. It is designed for fiber-coupled and free space applications. The S180C is compatible with all current Thorlabs power meter display units. A non-volatile memory in the sensor connector contains sensor information data and the NIST- and PTB-traceable calibration data.

An SM1 (1.035"-40) thread adapter and FC fiber adapter are included with the S180C; other fiber adapters for SMA, LC, ST and SC connectors can be purchased separately as accessories. 8-32- and M4-threaded tapped holes are provided for mounting to \varnothing 1/2" posts and post holders.

Specifications


S180C	
Detector Type	MCT (HgCdTe) Photodiode
Wavelength Range	2900 - 5500 nm
Optical Power Working Range	1 μ W - 3000 mW
Max Average Power Density	1 kW/cm ²
Max Pulse Energy Density	1 J/cm ²
Linearity	\pm 0.5%
Resolution ^a	10 nW
Measurement Uncertainty ^b	\pm 5%
Typical Application	Fiber Lasers / Low and Mid Power Lasers
Laser Types	QCL, ICL, He-Ne, CO, Er:YAG, Co ²⁺ :ZnS
Coating	Gold
Cooling	Convection
Head Temperature Measurement	NTC Thermistor 4.7k Ω
Console Compatibility	PM100D, PM100A, PM100USB, PM200, PM320E
Response Time	<1 μ s
Sensor Dimensions	59.0 x 50.0 x 28.5 mm
Active Detector Area	1 mm x 1 mm
Input Aperture	\varnothing 7 mm
Cable Length	1.5 m
Connector	Sub-D 9-Pin Male
Weight	0.25 kg
Post Mounting	8-32 & M4 Tapped Holes
Aperture Thread	Externally SM1-Threaded (1.035"-40) Removable Adapter
Fiber Adapters (Optional)	FC, SC, LC, SMA, ST

a. Measured with PM100D console in bandwidth low setting.


b. Beam diameter > 1 mm

Please note that the S180C power meter head is not compatible with the older Thorlabs power meter consoles (PM100, PM30, PM300, PM300E, S100).

Typical Response Graph



Drawings



Available Accessories

S120-SMA	SMA Fiber Adapter
S120-SC	SC Fiber Adapter
S120-LC	LC Fiber Adapter
S120-ST	ST Fiber Adapter
S120-FC	FC Fiber Adapter (Included)
SM1A20	SM1 (1.035"-40) Thread Adapter (Included)

The S180C is equipped with 8-32 and M4 tapped holes for compatibility with Thorlabs' imperial and metric post and post holder assemblies. When used with the SM1A20 thread adapter, the S180C is also compatible with SM1-threaded (1.035"-40) components.

Cleaning and Maintenance

There are no serviceable parts in the S180C head. The housing may be cleaned by wiping with a soft damp cloth. The integrating sphere inner surface cannot be cleaned, do not touch this surface. Gently blow off any debris using compressed air. If you suspect there is a problem with your S180C, please contact Thorlabs and an engineer will be happy to assist you.

As long as the sensor has not been exposed to excessive optical power (please pay attention to the maximum ratings in the technical specifications), the calibration should be very stable over long periods of time (well over a year). To keep the accuracy and performance of the S180C, Thorlabs recommends a yearly recalibration, starting one year after purchase.

Precautions and Warranty Information

These products are ESD (electro static discharge) sensitive and as a result are not covered under warranty. In order to ensure the proper functioning of a photodiode care must be given to maintain the highest standards of compliance to the maximum electrical specifications when handling such devices. The photodiodes are particularly sensitive to any value that exceeds the absolute maximum ratings of the product. Any applied voltage in excess of the maximum specification will cause damage and possible complete failure to the product. The user must use handling procedures that prevent any electro static discharges or other voltage surges when handling or using these devices.

Thorlabs, Inc. Life Support and Military Use Application Policy is stated below:

THORLABS' PRODUCTS ARE NOT AUTHORIZED FOR USE AS CRITICAL COMPONENTS IN LIFE SUPPORT DEVICES OR SYSTEMS OR IN ANY MILITARY APPLICATION WITHOUT THE EXPRESS WRITTEN APPROVAL OF THE PRESIDENT OF THORLABS, INC.

As used herein:

1. Life support devices or systems are devices or systems which, (a) are intended for surgical implant into the body, or (b) support or sustain life, and whose failure to perform, when properly used in accordance with instructions for use provided in the labeling, can be reasonably expected to result in a significant injury to the user.
2. A critical component is any component in a life support device or system whose failure to perform can be reasonably expected to cause the failure of the life support device or system or to affect its safety or effectiveness.
3. The Thorlabs products described in this document are not intended nor warranted for usage in Military Applications.

